TECHNICAL NOTE	Number	554
DATE: 7-Sep-00	Issue	1

TITLE:	fex21 Dial Up Instructions
ABSTRACT:	Steps required to connect the fex21 H/PC to an NT server

The following instructions can be used to connect an fex21 to an NT server via a PSTN modem connection. These instructions make use of the fex21 internal SoftModem but can be used with any Windows CE compatible modem.

- Plug PSTN cable into RJ11 socket on fex21
- On fex21 go to Start/Programs/Communication/Remote Networking

- Double Tap Make New Connection
- Ensure Dial Up Connection is checked



- Tap Next

The information contained in this document is copyright and may not be reproduced, stored in a retrieval system in any form by means of, electronic, mechanical, photocopying or otherwise without prior permission from the copyright holder, Itronix (UK) Limited.

Disclaimer. Whilst every precaution has been taken in the preparation of this document the publisher assumes no responsibility for errors and omissions. Neither is any liability assumed for damage resulting from the use of the information contained within this document.

Itronix (UK) Limited, Eden Road, Walsgrave Triangle Business Park, Coventry CV2 2TB, Telephone Coventry (024) 76 604040.

- Tap down arrow on Select Modem dialog box and select SoftModem on COM5 *(at this point you can change the modem selection to any Windows CE compatible modem you have installed within the system)*



- Tap Configure

  - Select Call Options tab
  - Within Extra Settings box type the following dial string:-
    s51=15f10%c0 (*This is only required when using the* fex21 *internal soft modem)*
- Tap OK to accept settings



The information contained in this document is copyright and may not be reproduced, stored in a retrieval system in any form by means of, electronic, mechanical, photocopying or otherwise without prior permission from the copyright holder, Itronix (UK) Limited.

Disclaimer. Whilst every precaution has been taken in the preparation of this document the publisher assumes no responsibility for errors and omissions. Neither is any liability assumed for damage resulting from the use of the information contained within this document.

Itronix (UK) Limited, Eden Road, Walsgrave Triangle Business Park, Coventry CV2 2TB, Telephone Coventry (024) 76 604040.

- Tap TCP/IP Settings
  - Uncheck Server Assigned IP Address



- Ensure Use Software Compression and Use IP Header Compression are checked if required by your server
- Enter the IP Address assigned to you by the network administrator.
  - Tap Name Servers Tab



- Uncheck Use Server Assigned Addresses
  - Enter server address details
  - Tap OK
- Tap Next



- Enter Dial Up phone details

The information contained in this document is copyright and may not be reproduced, stored in a retrieval system in any form by means of, electronic, mechanical, photocopying or otherwise without prior permission from the copyright holder, Itronix (UK) Limited.

Disclaimer. Whilst every precaution has been taken in the preparation of this document the publisher assumes no responsibility for errors and omissions. Neither is any liability assumed for damage resulting from the use of the information contained within this document.

Itronix (UK) Limited, Eden Road, Walsgrave Triangle Business Park, Coventry CV2 2TB, Telephone Coventry (024) 76 604040.

- Tap Finish

Important Note

Before the fex21 can be used for Dial Up connection you must use the following instructions for changing the default unit name:

- Go to Start/Settings/Control Panel
- Double tap the Communications icon
- Change device name from Handheld_PC to a name of your choice (The name must be unique on the Network)

The following steps describe the process for connecting the fex21 to the network once the Dial-Up Connection has been set up.

- Double tap the Dial Up Connection set up earlier
- Tap Dial properties
- Set relevant dial codes for your local area
- Tap Dialling Patterns
- Set required dialling patterns
- Tap OK on Dialling Patterns screen
- Tap OK on Dialling Properties screen
- Enter User Name, Password and Domain Name for your server



- Tap Connect
- A dialog box will appear and state when the unit is successfully connected
- Tap Hide and the dialog box will disappear
- From desktop open My Handheld PC
- In the Address bar enter the details of your server (e.g \\ServerName)
- You may be requested to re-enter the User, Password and Domain details. This is dependent upon the setup of the server.
- Once the details have been entered the fex21 will display a directory of the server using folders.

The information contained in this document is copyright and may not be reproduced, stored in a retrieval system in any form by means of, electronic, mechanical, photocopying or otherwise without prior permission from the copyright holder, Itronix (UK) Limited.

Disclaimer. Whilst every precaution has been taken in the preparation of this document the publisher assumes no responsibility for errors and omissions. Neither is any liability assumed for damage resulting from the use of the information contained within this document.

Itronix (UK) Limited, Eden Road, Walsgrave Triangle Business Park, Coventry CV2 2TB, Telephone Coventry (024) 76 604040.

To disconnect from the server double tap the connection icon in the systray and tap disconnect on the dialog box that appears.

The information contained in this document is copyright and may not be reproduced, stored in a retrieval system in any form by means of, electronic, mechanical, photocopying or otherwise without prior permission from the copyright holder, Itronix (UK) Limited.

Disclaimer. Whilst every precaution has been taken in the preparation of this document the publisher assumes no responsibility for errors and omissions. Neither is any liability assumed for damage resulting from the use of the information contained within this document.

Itronix (UK) Limited, Eden Road, Walsgrave Triangle Business Park, Coventry CV2 2TB, Telephone Coventry (024) 76 604040.